

T1200 Totem Display Unit Assembly Instructions



- 1 Stand the main panel upright so the 4 slotted tabs are facing up then peel back the protective film about 2 inches down. Then place the black shaper over the unit.



- 2 Position the base assembly over the upright panel so the 4 tabs locate in their corresponding slots through the base.



- 3 Slide the curved locking pegs through the slots located at the far left and far right. These lock the base in position to the main display panel.

T1200 Totem Display Unit Assembly Instructions



- 4 Carefully rotate the display into its normal standing position and peel back the film on the top about 2 inches down.



- 5 Push the lid into position taking care not to crease the edge of the paper insert when pushing down.



- 6 Your unit is ready for display!